## WEST TEXAS AND LUBBOCK RAILWAY

### SUPPLEMENT 1 TO FREIGHT TARIFF WTLC 8000

NAMING LOCAL AND PROPORTIONAL SWITCHING CHARGES AND

MISCELLANEOUS SERVICES
APPLYING

AT

STATIONS ON THE
WEST TEXAS AND LUBBOCK RAILWAY

#### **LOCAL TARIFF**

This tariff is also applicable on intrastate traffic, except where expressly provided to the contrary in connection with particular rates and provisions contained herein.

For reference to Governing Classification, see Item 5 of this tariff.

ISSUED: February 26, 2008 EFFECTIVE: March 17, 2008

#### **ISSUED BY**

Stephen C. Gregory
Vice President - Marketing
West Texas And Lubbock Railway Company
821 West Broadway
Brownfield, TX 79316

#### **SUPPLEMENT 1 TO FT WTLC 8000**

# **SWITCHING** (Charges are in dollars and cents per car, except as noted) **ITEM 400-A** INTRA-PLANT, INTER-PLANT AND INTRA-TERMINAL **SWITCHING CHARGES APPLICATION** CHARGE Intra-Plant (a) \$65.00 (b) \$100.00 (a) Switching to point on same track (b) Switching to a point on a different track Inter-Plant \$150.00 Intra-Terminal \$200.00 [I] (c)(e) \$400.00 Inter-Terminal (c)(f) \$450.00 (d)(e) \$450.00 (d)(f) \$500.00 (c) Freight originating at a station in Zone A, B or C and destined for a station in same Zone. (d) Freight originating at a station in Zone A and destined for a station in Zone B or vice versa. (e) Private Cars (f) Railroad Cars

For explanation of abbreviations and reference marks not explained herein, see Item 99999, this tariff.